





















TUBOLARI per SERRAMENTI in FERRO

<p><b>1A</b></p>  <p>Spessore 15/10 = Kg/ml 1,72</p>	<p><b>1B</b></p>  <p>Spessore 15/10 = Kg/ml 2,10</p>	<p><b>1C</b></p>  <p>Spessore 15/10 = Kg/ml 1,99</p>	
<p><b>2A</b></p>  <p>Spessore 15/10 = Kg/ml 1,76</p>	<p><b>2B</b></p>  <p>Spessore 15/10 = Kg/ml 1,88</p>	<p><b>2D</b></p>  <p>Spessore 15/10 = Kg/ml 2,78 - Spessore 20/10 = Kg/ml 3,66</p>	
<p><b>2N</b></p>  <p>Spessore 15/10 = Kg/ml 2,30</p>	<p><b>2T</b></p>  <p>Spessore 15/10 = Kg/ml 2,30</p>	<p><b>2Z</b></p>  <p>Spessore 15/10 = Kg/ml 1,88</p>	
<p><b>11A</b></p>  <p>Spessore 15/10 = Kg/ml 1,34</p>	<p><b>11B</b></p>  <p>Spessore 15/10 = Kg/ml 1,57</p>	<p><b>11C</b></p>  <p>Spessore 15/10 = Kg/ml 1,57</p>	
<p><b>14A</b></p>  <p>Spessore 15/10 = Kg/ml 1,79</p>	<p><b>15A</b></p>  <p>Spessore 15/10 = Kg/ml 2,04</p>	<p><b>15T</b></p>  <p>Spessore 15/10 = Kg/ml 2,45</p>	<p><b>15Z</b></p>  <p>Spessore 15/10 = Kg/ml 2,45</p>
<p><b>16A</b></p>  <p>Spessore 15/10 = Kg/ml 2,30 Spessore 20/10 = Kg/ml 3,08</p>	<p><b>16B</b></p>  <p>Spessore 15/10 = Kg/ml 2,30 Spessore 20/10 = Kg/ml 3,08</p>	<p><b>16Z</b></p>  <p>Spessore 15/10 = Kg/ml 2,55 Spessore 20/10 = Kg/ml 3,39</p>	
<p><b>16D</b></p>  <p>Spessore 20/10 = Kg/ml 4,65</p>			